Quick Start Guide

DW IP Cameras

MEGApix

DWC-MSB100BIW – 4K Vitrik Light Bullet Camera with Fixed Lens
DWC-MSB100BPW – 4K White Light Bullet Camera with a Vari-Focal Lens



Default login information: admin | admin

When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the DW IP Finder software or directly from the camera's browser menu.

WHAT'S IN THE BOX

Star Wrench (T-20)	1		Waterproof Cap	1 set	
Test Monitor Cable (DWC-MSB100BPW)	1		Rubber Plug (DWC-MSB100BPW)	1	
Screws and Plastic Anchors 4pcs	1 set		DWC-MSB100BPW Mounting Template	1	
Quick Setup and Download Guides	1 set		DWC-MSB100BIW Mounting Template	1	
Sunshield Adapter	1				

NOTE: Download all your support materials and tools in one place

1. Go to **http://www.digital-watchdog.com**
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable product numbers will be automatically based on the characters entered.
3. Click **"Search"**. All supported materials, including manuals and quick start guide (QSG's) will appear in the results.

Attention: This document is intended to serve as a quick reference for the initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage.

SAFETY AND WARNING INFORMATION

Read through this Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. See the user manual for more information on the proper installation, use and care of the product.

Failure to follow the instructions in this guide may result in damage to the product, injury to yourself and/or others. Warnings: Serious injury or death may occur if any of the warnings are not heeded.

Cautions: Injury or equipment damage may occur if any of the cautions are neglected.

WARNINGS:

1. At the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.
2. Do not connect two or more power supply adapters to the device unless otherwise specified. Using any other adapter could cause fire, electrical shock, or damage to the product.
3. Make sure the power supply voltage is correct before using the camera.
4. Do not touch the bare wire and the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product.
5. Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat generation or fire.
6. Securely plug the power cord into the power source. An insecure connection may cause a fire.
7. When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.
8. Do not place the camera in extremely hot locations (storage temperature above 60°C or 140°F). Otherwise, it may cause fire or electric shock.
9. Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.
10. Do not install the unit in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.
11. Do not install near any heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
12. Do not expose the product sunlight and heat radiation sources. It may cause a fire.
13. If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock.
14. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.
15. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.

CAUTION:


1. Use proper safety gear when installing and wiring the product.
2. Do not drop the camera or subject it to impact or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference.
3. Do not use this product near water.
4. Do not touch the image sensor (component) to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the product.
5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor.
6. The Main plug is used as a disconnect device and shall stay readily operable at any time.
7. Remove the power adapter from the outlet during lightning. Neglecting to do so may cause fire or damage to the product.
8. Do not block any ventilation openings. Install following the manufacturer's instructions.
9. A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the product.
11. If any visual anomaly or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock.
12. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.
13. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.

CAUTION:

1. Use proper safety gear when installing and wiring the product.
2. Do not drop the camera or subject it to impact or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference.
3. Do not use this product near water.
4. Do not touch the image sensor (component) to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the product.
5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor.
6. The Main plug is used as a disconnect device and shall stay readily operable at any time.
7. Remove the power adapter from the outlet during lightning. Neglecting to do so may cause fire or damage to the product.
8. Do not block any ventilation openings. Install following the manufacturer's instructions.
9. A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the product.
11. If any visual anomaly or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock.
12. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.
13. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.
14. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
15. Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
16. Do not aim the camera lens at the strong light such as sun or lamp.
17. Always use hardware (e.g., screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount.
18. Use only power supplies listed in the user manual or by the manufacturer, or sold with the product.
19. Unplug this product when it is not in use and also when cleaning. Use only a damp cloth (and combination to avoid injury from tip-over.
20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as: if the power supply cord or plug is damaged, liquid has been spilled, objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

STEP 1 – PREPARING TO MOUNT THE CAMERA

1. Using the camera's mounting bracket or mounting template, mark and drill the necessary holes in the mounting surface.



STEP 2 – POWERING THE CAMERA

Pass the wires through and make all necessary connections.

Use a PoE Switch or PoE Injector to connect and power to the camera using a single Ethernet cable.

DC12V, PoE, Adapter not included.

Use a non-PoE Switch to connect data using an Ethernet cable and use a power adapter to power the camera.




Power requirements	Power consumption
	DWC-MSB100BIW DC 12V: max 7.5W, 625mA PoE: max 7.5W, 156mA DWC-MSB100BPW DC 12V: max 11W, 925mA PoE: max 12.5W, 260mA

CAUTION:

1. Use proper safety gear when installing and wiring the product.
2. Do not drop the camera or subject it to impact or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference.
3. Do not use this product near water.
4. Do not touch the image sensor (component) to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the product.
5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor.
6. The Main plug is used as a disconnect device and shall stay readily operable at any time.
7. Remove the power adapter from the outlet during lightning. Neglecting to do so may cause fire or damage to the product.
8. Do not block any ventilation openings. Install following the manufacturer's instructions.
9. A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the product.
11. If any visual anomaly or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock.
12. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.
13. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.
14. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
15. Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
16. Do not aim the camera lens at the strong light such as sun or lamp.
17. Always use hardware (e.g., screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount.
18. Use only power supplies listed in the user manual or by the manufacturer, or sold with the product.
19. Unplug this product when it is not in use and also when cleaning. Use only a damp cloth (and combination to avoid injury from tip-over.
20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as: if the power supply cord or plug is damaged, liquid has been spilled, objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

If needed, install the waterproof cap.



NOTE: In extreme environments use of an outdoor rated sealer is recommended.



STEP 3 – INSTALLING THE CAMERA

2. Secure the camera to the mounting surface. Use the rubber plug depending on the wires installation.



3. Adjust the camera's tilt, pan and rotation.



4. Remove the protective film from the lens cover. Softly wipe the lens cover with lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process.

STEP 4 – CABLING AND EXTERNAL DEVICES



STEP 5 - MANAGING THE SD CARD (OPTIONAL)

1. Locate the SD card slot at the base of the camera.
2. Insert a class 10 SD card into the SD card slot until it clicks into position.
3. Press the card inward to release it from the card slot.

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32.
When inserting the SD card into the card slot, the SD card's contacts should be facing upward, as shown in the diagram.

NOTE: To use the Facial Recognition Analytics in your camera, insert an SD card (64GB or larger) **BEFORE USE**.

STEP 6 - DW IP FINDER

1. Download and install the DW IP Finder from the DW website.
2. Open the DW IP Finder and click 'Scan Devices' to find the camera on the network.
3. A password must be set when connecting to the camera for the first time.
   a. Check the box next to the camera.
   b. Click "Bulk Password Assign" on the left.
   c. Enter admin/admin for the current username and password. Enter a new username and password to the right.
   Password must have at least eight (8) characters and at least four (4) combinations of uppercase and lowercase letters, numbers and special characters. Passwords cannot contain the user ID.
   d. Click "change" to apply all changes.

STEP 7 – WEB VIEWER

The GUI display may differ by camera models.

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's view in the results table.
3. Press the 'Website' button. The camera's web viewer will open up in your default web browser.
4. Enter the camera's username and password you setup in the DW IP Finder. If you did not setup a new username and password via the DW IP Finder, a message will direct you to setup a new password for the camera before gaining access.

To open the camera using the web browser:

1. Open a web browser.
2. Enter the camera's IP address and port in the address bar. Example: http://<ipaddress>:<port>. Port forwarding may be necessary to access the camera from a different network. Contact your network administrator for more information.
3. Enter the camera's username and password you setup in the DW IP Finder.

NOTE: Some menu options may not be available based on the camera model. See the full manual for more information.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This products is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com.

Tel: +1 (866) 446-3595 / (813) 888-9555
Technical Support Hours: 9:00AM – 8:00PM EST, Monday through Friday
digital-watchdog.com

Rev: 10/26
Copyright © Digital Watchdog. All rights reserved.
Specifications and pricing are subject to change without notice.