Quick Start Guide

DWC-MGO2G28IRM - 4K White Light Vandal Dome Camera with Fixed Lens
DWC-MGO2G28IRPM - 4K White Light Vandal Dome Camera with 4 mm Fixed Lens

Default login information: admin | admin

When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the DW IP Finder software or directly from the camera's browser menu.

WHAT'S IN THE BOX

Star Wrench (T-20)		1	Waterproof Cap		1
Tool Monitor Cable (DWC-MGO2G28IRM)		1	Rubber Plug		1
Screws and Plastic Anchors – Back		1 set	DWC-MGO2G28IRM Mounting Template		1
Quick Setup and Download Guides		1 set	DWC-MGO2G28IRM Mounting Template		1

NOTE: Download all your support materials and tools in one place

1. Go to **http://www.digital-watchdog.com/resources**
2. Search your product by entering the part number in the **'Search by Product'** search box. Please note that part numbers will populate automatically based on the part number you enter.
3. Click **'Search'** to view the available downloads.
4. Download the user manual, software, and tools.

Attention: This document is intended to serve as a quick reference for the initial set-up. It is recommended that the user read the entire instruction manual before attempting to proceed with proper installation and usage.

SAFETY AND WARNING INFORMATION

Read through the Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. Follow all safety and warning information to prevent injury to yourself and others, or damage to property. These instructions are intended to ensure that users can use the product correctly to avoid danger or property loss. Failure to follow the safety precautions may result in serious injury or death.
Cautions: Injury or equipment damage may occur if any of the cautions are disregarded.

WARNING

1. In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.
2. If smoke, odor or noise arises from the product, turn off the power immediately, unplug any other adapter could cause fire, electrical shock, or damage to the product.
3. Make sure the power supply voltage is correct before using the camera.
4. Do not drop the product or subject it to physical shock. Do not touch sensor modules. Improper use can cause an explosion, fire, electric shock, or damage to the product.
5. Do not use liquid, aerosol, or solvents to clean unit. Unplug the camera's power adapter or add with the product.
6. Do not plug the power cord into the power source. An insecure connection may cause a fire.
7. Before installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.
8. Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or damage to the product.
9. Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.
10. Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.
11. Do not block any air openings. Install following the manufacturer's instructions.
12. Keep out of direct sunlight and heat radiation sources. It may cause a fire.
13. Do not aim the camera lens at strong sources of light such as sunlight or infrared at once. Immediately disconnect the power source and call a customer service center. Continued use of such a condition may cause fire or electric shock.
14. Do not dismantle or alter. Do not operate normally, contact the nearest service center. Never disassemble or change the product in any way.
15. When cleaning the product, do not wipe sensor modules and other parts of the product. Doing so may cause the camera to electric shock.

CAUTION

1. Use the proper safety gear when installing and wiring the product.
2. Do not drop objects on the product and apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference.
3. Do not install in high humidity environment.
4. The product shall not be exposed to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the product.
5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor.
6. The Plug-in Jack is used as a disconnect device and shall stay readily operable at any time.
7. Remove the power adapter from the outlet during lightning. Neglecting to do so may cause fire or damage to the product.
8. Do not block any ventilation openings. Install following the manufacturer's instructions.
9. Do not touch the sensor module with fingers. If cleaning is necessary, please use a clean cloth soaked with a little ethanol and wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
10. Use only attachments/accessories specified by the manufacturer.
11. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. When a cart is used, use caution when moving the cart/product combination to avoid injury from tip-over.
12. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as if the power supply cord or plug is damaged, liquid has been spilled, objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

STEP 1 - PREPARING TO MOUNT THE CAMERA

1. For the installation, remove the camera cover and camera module from the mounting bracket by loosening the camera module and cover assembly screws.

2. Using the camera's mounting bracket or mounting template, mark and drill the necessary holes in the mounting surface.

STEP 2 - POWERING THE CAMERA

Pass the wires through and make all necessary connections.

Use a PoE Switch or PoE Injector to connect data and power to the camera using a single Ethernet cable.

Use a non-PoE Switch to connect data using an Ethernet cable and use a power adapter to power the camera.

Power requirements	Power consumption
DC12V, PoE (IEEE 802.3af class 2) Adapter not included.	DWC-MGO2G28IRM PoE: max 7.5W, 150mA PoE+: max 7.5W, 150mA DWC-MGO2G28IRPM PoE: max 10.8W, 270mA PoE+: max 10.8W, 220mA

If needed, install the waterproof cap.

NOTE: In extreme environments use of an outdoor rated sealer is recommended.

STEP 3 - INSTALLING THE CAMERA

1. Mount the camera using the included screws and anchors.

2. Adjust the camera's tilt, pan and rotation.

3. Assemble the dome cover over the camera body. Align the dome and bottom case to match the case outline.

4. Remove the protective film from the dome. Softly wipe the dome with lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process.

STEP 4 - CABLING AND EXTERNAL DEVICES

STEP 5 - MANAGING THE SD CARD (OPTIONAL)

1. Locate the SD card slot at the base of the camera.
2. Insert a class 10 SD card into the SD card slot until it clicks into position.
3. Press the card inward to release it from the card slot.

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32
When inserting the SD card into the card slot, the SD card's contacts should be facing upward, as shown in the diagram.

NOTE: To use the Facial Recognition Analytics in your camera, insert an SD card 64GB or larger) **BEFORE USE.**

STEP 6 - DW IP FINDER

1. Download and install the DW IP Finder from the DW website.
2. Open the DW IP Finder and click 'Scan Devices' to find the camera on the network.
3. The camera will be set when connecting to the camera for the first time.
   a. Check the box next to the camera.
   b. Click "Bulk Password Assign" on the left.
   c. Enter admin/admin for the current username and password. Enter a new username and password to the right. Password must have at least eight (8) characters and at least four (4) combinations of uppercase and lowercase letters, numbers and special characters. Passwords cannot contain the user ID.
   d. Click "change" to apply all changes.

STEP 7 - WEB VIEWER

The first display may differ by camera models.

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's row on the results table.
3. Press the 'Website' button. The camera's web viewer will open up in your default web browser.
4. Enter the camera's username and password you setup in the DW IP Finder. If you did not setup a new username and password via the DW IP Finder, a message will direct you to setup a new password for the camera before gaining access.

To open the camera using the web browser:

1. Open a web browser.
2. Enter the camera's IP address and port in the address bar. Example: http://<ipaddress>:<port>. Port forwarding may be necessary to access the camera from a different network. Contact your network administrator for more information.
3. Enter the camera's username and password you setup in the DW IP Finder.

NOTE: Some menu options may not be available based on the camera model. See the full manual for more information.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This product is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com.

Tel: +1 (866) 446-3595 / (813) 888-9555
Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday
digital-watchdog.com

Copyright © Digital Watchdog. All rights reserved.
Specifications and pricing are subject to change without notice.

Part No. 10126