Quick Start Guide

MEGApix Ai
Next-generation video analytics

IVM-5058A



Default login information - admin / admin

When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the DW IP Finder software or directly from the camera's browser interface.

WHAT'S IN THE BOX

Star Bracket, Short	1	Audio Connector Tool and Terminal Block	1 each
Star Positioner	1	Sun Shield Cover and Terminal Block	2 each
Screws and Plastic Anchors (Camera Mount)	1 set	Terminal Block	1
Mounting Template	1	Screw Set-up and Reset/Default Tool	1 each
Ferrite Core	1	Screws for electric gang box (EU) (2 x M3.5x8, 2 x M3.5x12)	1 set

NOTE: Download all user support materials and tools in one place:

1. Search for product model number (IVM-5058A).
2. Select your product from the search results and click the **Tools by Product** tab.
3. Download the latest version of the software tools manually based on the user's browser environment.

Alternatively, for Windows® users, including Network:

1. Browse to the camera's IP address in Windows Explorer.

Attention: This document is intended to serve as a quick reference for the initial set up. It is recommended that the user refer to the full user manual for complete and proper installation and usage.

SAFETY AND WARNING INFORMATION

Read through and follow all safety instructions before using this product. Keep the installation Guide for future reference. See the user manual for more information on the proper installation, use and care of the product.

- Do not attempt to disassemble the camera. To reduce the risk of electric shock, do not remove screws or covers other than those specified in the installation instructions. There are no user serviceable parts inside. Refer servicing to qualified service personnel.
- In the case of the product, you must be strict compliance with the electrical safety regulations of the nation and region. Please check the power supply specifications in the user manual. (DC 12V, AC 24V)
- Please do not use the product in high temperature, low temperature or humidity. Using any other operation environment may cause the product to malfunction.
- Make sure the power supply voltage is correct before using the camera.
- Do not drop the camera or subject it to physical shock. Do not touch the sensor module with fingers. If cleaning of the sensor module is necessary, use a clean cloth moistened with a small amount of ethanol and wipe gently. If the camera will not be used for an extended period of time, put on the supplied lens mount cover to protect the sensor from dirt.
- Do not aim the camera lens at strong light sources. Strong light sources may cause blooming or other undesired effects.
- Do not expose the camera to rain or moisture, or try to use it near water. Immediately disconnect the camera if it is exposed to water. Allow the camera to completely dry before reconnecting it to the power source.
- Do not place the camera in an area with excessive smoke, condensation, dust, vibration, chemicals, or explosive materials. Avoid exposure to X-ray machines.
- The product should not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product.
- Do not block the camera's ventilation openings or mount the camera to a hot surface. Doing so may damage the camera.
- Use only accessories specified by the manufacturer.
- Do not operate the camera beyond the specified temperature, humidity or power source ratings.
- Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions and should use a mounting accessory recommended by the manufacturer.
- Do not attempt to modify or repair the camera. Contact your dealer for assistance.
- Power-line voltage must meet the limited power source (LPS) according to IEC 60950-1 or PS2 according to IEC 62368-1 standard. Please refer to the label for more information.
- Use only with UL listed computer with limited power source.

STEP 1 - PREPARING TO MOUNT THE CAMERA

1. Run the installation, Micro SD card, alarm modules, junction box and mounting plate. Using the wrench included with the camera, loosen the three (3) screws connecting the camera modules to the junction box and the three (3) screws connecting the junction box to the mounting plate.



2. Using the mounting template, drill the camera's mounting plate, mark and drill the necessary holes in the mounting surface.


STEP 2 - POWERING THE CAMERA

Pass the wires through the camera's junction box and make all necessary connections.

Use a PoE Switch that meets IEEE 802.3at standard to connect data and power to the camera using a single Ethernet cable.

OR

Use a PoE Switch to connect data using an Ethernet cable and use a power adapter to power the camera.



Power Information	
Power Consumption	DC12V: PoE: 18.9W, 802.3af Class3 (Adapter not included) 12V, DC: max 17.4W, 1.45A 24V, AC: max 20.83W, 420mA
Power Connector	DC Jack
Connector	5.5mm x 2.1mm

Install the ferrite core on the LAN cable to reduce high-frequency noise:


- Close the ferrite core by fitting the clasps dry.
- Make one loop with the cable through the ferrite core.
- Close the ferrite core to hold the cable loop in place.



Resetting the camera: With the camera ON, press the reset button for five (5) seconds to restore a camera-wide reset of all the settings, including network settings.

STEP 3 - INSTALLING THE CAMERA

1. Attach the mounting plate to the mounting surface using the included anchors and screws. Please note that the camera cannot be mounted without the gang box bracket.




Gang Box Installation Options

a) Use the 2 screws (A) included with the converter plate when using a 2-gang handy electrical box or switch box.




b) Use the 2 screws (B) included with the converter plate when using a 1-gang handy electrical box.



3. Assemble the junction box and mounting plate. Align the markings on the camera and junction box when assembling the camera.



4. Connect the camera to the junction box using the safety wire.



5. Adjust each camera's tilt and angle by loosening the tilt screw at the camera's arm. Tighten the screw once the adjustment is complete.



6. Remove the protective film from the lens cover. Gently wipe the cover with lens tissue or a microfiber cloth to remove any dust or smudges left from the installation process.

NOTE: When calibrating the camera for the first time, use the CALIBRATE button on the camera's web GUI to auto calibrate the camera's lens before operation.

STEP 4 - CABLING AND EXTERNAL DEVICES

1. **Network cable** - To connect an RJ45 cable to the camera:

Option A (Recommended):
a. Remove the gasketed plug.
b. Pass the network cable through the grommet at the base of the camera.
c. Once the cable is through, pull the RJ45 connector.



Option B:
a. Attach the included RJ45 installation tool to the network cable.
b. Remove the grommet plug.
c. Pass the network cable through the grommet. Pay attention to the direction of the installation tool.
d. Once the cable's connector is through, remove the installation tool.



Once the network cable is passed through the grommet:
a. Insert the grommet into the bottom of the camera base.



NOTE: Bending the cable may cause water leakage.

d. Connect the RJ45 to the camera's network input in the camera.

2. **Power** - See STEP 2.

3. **Sensor/Alarm Input (DI)** - Connect an alarm input device to 1 and - of the Terminal Block.

4. **Relay/Alarm Out (DO)** - Connect alarm lights or siren (normal open or normal close) to the + and - of the Terminal Block.

5. **Audio Input/Output** - Connect an amplifier or speaker to the audio output in the Terminal Block.


NOTE: The camera supports either audio input OR microphone and speaker (enabled by default). To use the audio input and output, disable the built-in microphone or speaker on the camera's web settings first.





STEP 5 - MANAGING THE SD CARD (OPTIONAL)

1. Locate the micro SD card slot at the base of the camera.
2. Insert a Micro SD micro SD card into the micro SD card slot until it clicks into position.
3. Press the card inward to release it from the card slot.



Micro SD Card Slot

NOTE: Maximum micro SDXC card size supported: Up to 1TB micro SD / FAT32. When inserting the micro SD card into the card slot, the micro SD card's contacts should be facing upward, as shown in the diagram.

STEP 6 - DW IP FINDER

Download and install the DW IP Finder from the DW website.

1. Open the DW IP Finder and click 'Save Device(s)' to find the camera on the network.
2. Select the camera and tick 'set when connecting to the camera' for the first time.
3. Click the camera next to the camera.
4. Click 'Auto Password Assign' on the left.
5. Enter admin/admin for the current username and password. Enter a new username and password for the camera.

Password must have at least eight (8) characters and contain three (3) of the following: uppercase letters, lowercase letters, numbers and special characters. Password cannot contain the user ID.

6. Click 'Change' to apply all changes.

STEP 7 - WEB VIEWER

* The GUI display may differ by camera model.

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's view in the results table.
3. Press the 'View Camera Website'.
4. Enter the camera's username and password you set up in the DW IP Finder.
   If you did not set up a new username and password, you will be prompted to set up a new password on the camera.

NOTE: Please see the full product manual for web viewer setup functions and camera settings options.

NOTE: This product is covered by one or more claims of the H.E.V.C. patents listed at patentlist.accessadvance.com

Copyright © Digital Watchdog. All rights reserved.
Specifications and pricing subject to change without notice.

Tel: +1 (866) 446-3595 / (813) 888-9555
Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

digital-watchdog.com