DW

Quick Start Guide

MEGAPix.AI

Next-generation video analytics

DWC-XFPA05AI / 5MP model

DWC-XFPA12AI / 12MP model

Default login information: admin / admin

When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the DW IP Finder software or directly from the camera's browser menu.

WHAT'S IN THE BOX

Star Wrench (T-20)	1	Camera	1	Installation Tool	1
Tool Monitor Cable	1	Mounting Bracket	1	Anchor and Installation Guide	1
Screws and Plastic Anchors (4ea)	1	Waterproof Gasket	1	Grommet	1
Quick Setup and Download Guide	1	Cable	1	Mounting Template	1
Mounting Bolts & Screws	1 set				

NOTE: Download all your user's support materials and tools in one place:

1. Go to **http://www.digital-watchdog.com/resources/**
2. Enter your camera's model number and click **"search by Product"** search
3. Download the support materials and software updates for your camera.
4. Click **"Search"** all supported materials, including manuals
5. Click **"Software"** all supported software and tools

Installation Tip: Before installing the camera, review the contents for the tools that will be recommended. Walk the user read the entire installation manual for a complete and proper installation and setup.

SAFETY AND WARNING INFORMATION

Please read the following safety information carefully before you begin the installation. Keep the installation guide for future reference. Do not disassemble the camera for any reason. Doing so will void all warranties.

Avoid installing the camera in wet locations. Do not expose the camera to rain or moisture. An electric shock or damage to the product.

Do not install the camera in extreme temperatures. Refer to the camera's specification. An electric shock or damage to the product.

Do not install the camera in unstable locations. Doing so may cause fire or electric shock.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not expose the camera to electrical shock or surges. It may cause fire.

If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact us. Continued use in such a condition may cause damage to the product or fire.

Do not drop objects on the camera or apply excessive pressure to it. Avoid installing in areas where vibrations occur.

Do not clean the product. Do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.

CAUTION

Do not install the camera in areas where the temperature exceeds 50°C. It may cause fire or camera malfunction. Operation or magnetic interference.

Do not aim the camera lens at bright lighting or splashing, and so objects filled with liquids, such as vases, shall be placed on the apparatus.

Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor.

Do not install the camera in humid environments. Doing so may cause fire or electric shock.

Remove the plastic protective film from the camera dome cover before operating. Failure to do so may cause reduced image quality due to the protective film.

Be careful not to drop the camera during installation. Additional caution should be taken when installing ceiling mounted products.

Be careful not to scratch or contaminate the camera lens during installation. Touching the lens directly with your fingers, scratches with sharp objects, or exposing it to harsh environments may damage the image quality.

Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the camera.

Only use attachments/accessories specified by the manufacturer. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

Proper configuration of passwords and other security settings is the responsibility of the installer and/or end-user.

Use only power supplies listed in the user manual or the user guide. The product will be used for a long time, please observe the following safety precautions carefully.

Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe gently. If the camera will not be used for an extended period of time, please put on the lens cap to protect the sensor from dirt.

Do not attempt to open the camera housing. There are no user serviceable parts inside. Opening the housing will void your warranty.

Be careful with rain, avoid heavy breeze, or while operating the product, or sold with the product.

Do not attempt to service beyond that described in these instructions. Refer all servicing to qualified service personnel.

Be careful to keep a qualified backup personnel. Servicing is needed when the product has been damaged in any way, such as if the power supply cord or plug is damaged, liquid has been spilled, objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

STEP 1 - PREPARING TO MOUNT THE CAMERA

1. For the installation, remove the camera cover and camera module from the mounting bracket by loosening the camera module screw counterclockwise.



2. Remove the existing moisture packet and insert the new packet in its place. The camera will generate enough heat to dry it during normal daily operations. In case of a moisture issue, keep the moisture absorber in the camera for up to six (6) months.



WARNING: The moisture absorber prevents moisture buildup inside the camera, which may cause image performance issues and damage the camera.

3. Using the camera's mounting bracket or mounting template, mark and drill the necessary holes in the mounting surface.

STEP 2 - POWERING THE CAMERA

Pass the cables and make all necessary connections.

Use a PoE Switch or PoE Injector to power the camera. Connect the camera using a single Ethernet cable.



OR

Use a non-PoE Switch to connect data using an Ethernet cable and a power adapter to power the camera.



Power Information	
Power requirements	DC12V, PoE IEEE 802.3af (Adapter not included)
Power consumption	DWC-XFPA05AI: PoE: 9.5W, 12VDC: 7.5W, 24VAC: 7.5W DWC-XFPA12AI: PoE: 10.5W, 12VDC: 8.5W, 24VAC: 8.5W
Maximum distance	328' (100m)
Connector	RJ45

STEP 3 - INSTALLING THE CAMERA

4. Attach the camera to the mounting surface using the included anchors and screws.



5. To mount the camera using the mounting bolt and screw:
   a. Secure the mounting screws to the camera's base.
   b. Use the mounting nuts to secure the camera to the mounting surface.



6. Assemble the dome cover over the camera body. Align the dome and bottom case to match the case outline.

NOTE: Be careful not to alter the direction of the camera module.



7. Adjust the camera's pan by rotating the base of the camera module.



8. Remove the protective film from the dome. Softly wipe the dome with lens tissue or a microfiber cloth to remove any dust or smudges left from the installation process.

STEP 4 - CABLING AND EXTERNAL DEVICES

1. **Network cable** - To connect RJ45 cable to the camera:
   a. Remove the gasket and grommet.
   b. Remove the grommet plug.
   c. Pass the network cable through the grommet at the base of the camera.
   c. Once the cable is through, add the RJ45 connector.



Option B:

   a. Attach the included RJ45 installation tool to the network cable.
   b. Remove the grommet plug.
   c. Pass the network cable through the grommet. Pay attention to the direction of the grommet connection.
   d. Once the cable's connector is through, remove the installation tool.



Once the network cable is passed through the grommet
   e. Insert the grommet at the bottom of the camera base.



NOTE: Bending the cable may cause water leakage.



   d. Connect the RJ45 to the camera's network input in the camera.



2. **Power** - See STEP 2
3. **Sensor/Alarm Input (DI)** - Connect an alarm input device to + and - of the Terminal Block.
4. **Relay/Alarm Out (DO)** - Connect alarm lights or siren (normal open or normal close) to the + and - of the Terminal Block.
5. **Audio Input/Output** - Connect an amplifier or speaker to the audio output in the Terminal Block.



+	-	+	-	+	-	N	COM	OUT
DC12V		DI		DO		AUDIO		

STEP 5 - MANAGING THE SD CARD (OPTIONAL)

1. Locate the SD card slot at the base of the camera.
2. Insert a class 10 SD card into the SD card slot until it clicks into position.
3. Press the card inward to release it from the card slot.

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32.
When inserting the SD card into the card slot, the SD card's contacts should be facing upward, as shown in the diagram.



STEP 6 - DW IP FINDER

1. Download the DW IP Finder from the DW website.
2. Open the DW IP Finder and click 'Scan Devices' to find your camera on the network.
3. A password must be set when connecting to the camera for the first time.
   a. Check the box next to the camera.
   b. Click the 'Change Password' icon on the left.
   c. Enter admin/admin for the current username and password. Enter a new username and password to the camera.

NOTE: Passwords must have at least eight (8) characters and at least four (4) combinations of upper/case and lower/case letters, numbers and special characters. Example: Abcd1234!

4. Click 'Change' to apply all changes.

STEP 7 - WEB VIEWER

This first display may differ by camera model.

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's row in the results table.
3. Press the 'View Camera Website' button.
4. Your web browser will open and a password you set up in the DW IP Finder. Enter a new username and password, you will be prompted to set up a new password to view the video.



NOTE: Please see the full product manual for web viewer features, and camera setup options.

NOTE: This procedure is covered by one or more claims of the MEVC Technologies patent portfolio license.

Tel: +1 (866) 446-3595 / (813) 888-9555

Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

digital-watchdog.com

Copyright © Digital Watchdog. All rights reserved.
Specifications and pricing subject to change without notice.