DW

Quick Start Guide

MEGAPix.AI

Next-generation video analytics

DWC-XMDF23H





Default login information: admin | admin

When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the DW IP Finder software or directly from the camera's browser menu.

WHAT'S IN THE BOX



Star Wrench (T-20)

1

Audio Installation Tool



Tool Monitor Cable

1

Window Installation Sticker (Recommended)



Ferrite Core

1 set

Grommet

Quick Setup and Download Guide

1

ACCESSORIES REQUIRED TO INSTALL THE CAMERA (SOLD SEPARATELY)



Wall mount (Installation Guide)



Ceiling mount (Installation Guide)



Junction box (Installation Guide)



Pendant mount (Installation Guide)



Waterproof mount bracket (DWC-PDP40UMWM) mount for pendant mount (Installation Guide)

NOTE: Download all your support materials and tools in one place.

1. Go to **http://www.digital-watchdog.com/resource/**.
2. Enter your camera's model number and select **"Search by Product"** search bar. Results for applicable part numbers will populate the instructional and support documents.
3. Click **"Search"**. All documents related to your camera, including the Quick Start and batch start guide (QSG) will appear in the results.

Attention: This document is intended to serve as a quick reference for the initial set up. It is recommended that you refer to the User Manual for more detailed information on installation and usage.

SAFETY AND WARNING INFORMATION

Read through the Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. Follow all safety precautions and warnings when installing and using the product.

These instructions are intended to ensure that users can use the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected.

Cautions: Injury or damage to the product may occur if any of the cautions are neglected.

Installation

- Do not drop the product, do not install it near areas affected by the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.
- Do not connect multiple cameras to a single power adapter. Exceeding the capacity of the power adapter could cause excessive heat or fire hazard.
- Do not block any ventilation openings. Install following the manufacturer's instructions.
- If a plastic or grounding hook plug is required to connect the product. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Do not locate the product where the cable can be run over, tripped over or damaged. If the device is mounted to a ceiling, the power cord must be secured using a secondary means.
- Do not touch the sensor modules with fingers. If cleaning is necessary, please use a clean cloth with a little ethanol applied. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
- Do not aim the camera lens at strong light sources such as the sun or incandescent lamps. Strong light can cause fatal damage to the camera.
- Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Do not connect to multiple devices personal. Service is needed when the product has been damaged in any way, such as if the power supply cord or plug is damaged, liquid has been spilled, objects have fallen into the product, the product has been exposed to rain or moisture, or does not operate normally, or has been dropped.

STEP 1 - PREPARING TO MOUNT THE CAMERA

1. For the installation, remove the camera cover and camera module from the mounting bracket by loosening the camera module and cover assembly screws.



2. Remove the existing moisture packet and insert the new packet in its place. The camera will generate enough heat to dry moisture during operation. In case of a moisture issue, keep the moisture absorber in room temperature for up to six (6) months.



WARNING! The moisture absorber prevents moisture buildup inside the camera, which may cause image distortion and condensation that damage the camera.

3. Using the mounting accessory, mark and drill the necessary holes in the mounting surface.

STEP 2 - POWERING THE CAMERA

Please review through and follow all necessary considerations.

Use the PoE injector included with the camera to connect data and power to the camera using a single Ethernet cable.

Use a non-PoE Switch to connect data using an Ethernet cable and a power adapter to power the camera.



NOTE: When using the PoE+ injector, do not connect the camera to a PoE switch, router, or PoE/PoE+ enabled port of PoE / PoE+ switch.

Power consumption

Power requirements	DC12V PoE IEEE 802.3at PoE injector included)
Power consumption	PoE: Max 25.5W, Typ. 19.5W PoE+: Max 30.8W, Typ. 17.5W
Maximum distance	328' (100m)
Connector	RJ45

Install the ferrite core on the LAN cable to reduce high-frequency noise.



- Open the ferrite core by lifting the closing clip.
- Make one loop with the cable through the ferrite core.
- Close the ferrite core to hold the cable loop in place.

STEP 3 - INSTALLING THE CAMERA

4. Connect all cables and external devices to the camera. See STEP 4.

Wiring



5. Secure the camera to the mounting bracket using the included screws. Make sure to align the wedge on the side of the camera with the one on the mounting bracket. Rotate the camera clockwise to lock into position.



6. The camera's four (4) individual sensors can be tilted to adjust the camera's views. The lens module's max tilt is 20°.



7. Assemble the dome cover over the camera body and detach the protective film to complete the installation. Be careful not to touch the dome cover with bare hands. Use a clean cotton cloth with ethanol to remove any dust or smudges left from the installation process.



STEP 4 - CABLING AND EXTERNAL DEVICES

1. **Network cable** - To connect an RJ45 cable to the camera

Option A (Recommended):

a. Remove the grommet plug.

b. Pass the network cable through the grommet at the base of the camera.

c. Once the cable is through, add the RJ45 connector.





Option B:

a. Attach the included RJ45 installation tool to the network cable.

b. Remove the grommet plug.

c. Pass the network cable through the grommet. Pay attention to the direction of the grommet connection.

d. Once the cable's connector is through, remove the installation tool.



Once the network cable is passed through the grommet.

e. Insert the grommet into the bottom of the camera base.



NOTE: Bending the cable may cause water leakage.



g. Connect the RJ45 to the camera's network input in the camera.

2. **Power** - See STEP 2.

3. **Sensor/Alarm input (DI)** - Connect an alarm input device to + and - of the Terminal Block.

4. **Relay/Alarm Out (DO)** - Connect alarm lights or siren (normal open or normal close) to the + and - of the Terminal Block.

5. **Audio Input/Output** - Connect an amplifier or speaker to the audio output in the Terminal Block.

STEP 5 - MANAGING THE SD CARD (OPTIONAL)

1. Locate any of the four (4) SD card slots at the base of the camera.
2. Insert a class 10 SD card into the SD card slot until it clicks into position.
3. Press the card inward to release it from the card slot.

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32. When inserting the SD card into the card slot, the SD card's contacts should face upward, as shown in the diagram.

STEP 6 - DW IP FINDER

1. Download and install the DW IP Finder from the DW website.
2. Open the DW IP Finder and click 'Scan Devices' to find the camera on the network.
3. A password must be set when connecting to the camera for the first time.
   a. Check the box next to the camera.
   b. Click "Bulk Password Assign" on the left.
   c. Enter a password. Enter the same username and password. Enter a new username and password to the right.
   Password must have at least eight (8) characters and at least four (4) combinations of uppercase and lowercase letters, numbers and special characters. Passwords cannot contain the user ID.
   d. Click "change" to apply all changes.

STEP 7 - WEB VIEWER

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's view in the results table.
3. Press the 'View Camera' button.
4. Enter the camera's username and password you set up in the DW IP Finder. If you did not set up a new username and password, you will be prompted to set up a new password to view the video.

* The GUI display may differ by camera model.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This product is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com.

Copyright © Digital Watchdog. All rights reserved.
Specifications and pricing are subject to change without notice.

Tel: +1 (866) 446-3595 / (813) 888-9555
Technical Support Hours: 8:00AM - 8:00PM EST, Monday through Friday

digitalwatchdog.com

digital-watchdog.com/kb

DW-22125