

DWC-XMDS20Mi



NOTE: Download all your support materials and tools in one place.




NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This products is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com.




BOX CONTENT




ACCESSORIES REQUIRED TO INSTALL THE CAMERA (SOLD SEPARATELY)

Wall mount: DWC-MDSWM	Hanging mount: DWC-MDSHM	Ceiling mount: DWC-MDSCM	Junction box: DWC-MDSJUNC	In-ceiling flush mount: DWC-MDSFM
--------------------------	-----------------------------	-----------------------------	------------------------------	--------------------------------------

1 Disassemble the camera for the installation.




2 Replace the moisture absorber.





3 Connect the network cable through the grommet.


Option A (Recommended):




Option B:




4 Cables and external devices.




5 4x Micro SD cards (optional).




6 Secure the camera base to the mounting accessory.



7 Adjust lenses tilt.



8 Assemble the camera cover to complete the installation.



Download quick setup guide, manual, IP Finder and firmware here:

